



# Base·X User Manual



Version 1.14  
13 April 2017

### Revision History

Revision	Revision Date	Changes	Name
Version 1.00	2013-04-06	First Version of Manual	Chris Bueley
Version 1.01	2013-04-26	Updates	Chris Bueley
Version 1.02	2013-05-13	Updated SeaCast version	Chris Bueley
Version 1.03	2013-06-13	Format revision and updates	Jehan Zouak
Version 1.04	2013-08-26	Minor Edits	Jehan Zouak
Version 1.05	2014-07-16	Added Ordering Codes	Jehan Zouak
Version 1.06	2014-10-06	Edited Charging section	Jehan Zouak
Version 1.07	2015-02-25	Updated Sensor Current Draw and Battery Life	Quinton Calverley
Version 1.08	2015-03-18	Updated manual for SeaCast 4	Andrew Beak-Taylor
Version 1.09	2015-04-29	Data•Xchange and formatting edits	Jehan Zouak
Version 1.1	2015-06-22	Updated technical specifications	Jehan Zouak
Version 1.11	2015-11-24	Updated manual to include CT•Xchange™ and updated product codes.	Tony Nordstrom
Version 1.12	2016-06-03	Added 500 m variant	Andrew Beak-Taylor
Version 1.13	2017-03-06	Minor updates	Jehan Zouak
Version 1.14	2017-04-13	Added regulatory info and greasing instructions	Andrew Beak-Taylor

---

## Table of Contents

General Description of the Instrument.....	2
Where Do I Start? .....	3
Shipping & Receiving .....	4
Receiving an Instrument .....	4
Returning an Instrument to the Factory.....	4
Using the Instrument .....	5
Pressure Ratings .....	5
Pre-Deployment Procedures.....	5
Supported Sensor Configurations.....	6
LED Indicator .....	7
Configuring Sampling Parameters Using SeaCast .....	8
Configuring Sampling Parameters through the Terminal .....	8
Accounting for Atmospheric Pressure Variations at the Surface.....	8
Logging a Profile .....	9
Monitoring Real Time Data .....	9
Post-Deployment Procedures .....	10
Viewing your Data.....	10
Configuring the Instrument for Data on Power Up .....	12
Disabling Data on Power Up.....	12
Maintaining the Instrument.....	13
Periodic Maintenance .....	13
Battery Care.....	13
Battery Life.....	13
Charging the Lithium-Ion Batteries .....	14
Communications .....	15
PC Settings.....	15
Output Formats.....	15
Default Output Format.....	15
Default Example Outputs: .....	16
Support .....	18
Troubleshooting .....	18
Contact AML Oceanographic.....	21
Appendices .....	22
Commands .....	22
Communications Commands .....	22
Sampling Rate Commands .....	22
Output Format Commands.....	23
Logging Commands .....	24
General Commands.....	24
Technical Specifications .....	25
Ordering Codes.....	27
Regulatory Information.....	28
Warranty .....	28
Technical Overview Drawings .....	29

## General Description of the Instrument

The AML Oceanographic X-Series instruments and sensors are a major advancement in ocean instrumentation. Swappable and interchangeable sensors dramatically improve the capabilities of ocean instrumentation in the following ways:

- Change the instrument sensor types while at sea within seconds, and without tools. A CTD can be changed to a sound speed profiler by exchanging sensor heads.
- To optimize the resolution and accuracy of sensor data, sensors can be swapped to change the measurement range. For example, a 6000 dBar P•Xchange pressure sensor can be swapped with a 500 dBar P•Xchange sensor; the salt water C•Xchange conductivity sensor can be swapped for a fresh water C•Xchange conductivity sensor.
- Sensors from one instrument can be swapped to another instrument to maintain mission-critical capabilities.
- Calibrated sensors can be sent from the factory to the instrument. The instrument is not pulled from active duty for calibration.
- Spare sensors ensure that an instrument can be immediately returned to active duty after sustaining damage.
- All calibration and traceability data resides within each Xchange sensor. Calibration data for all sensors is available from the instrument, and calibration certificates can be printed from AML Oceanographic SeaCast software when the instrument is connected.
- Logged data is stamped with sensor traceability and instrument configuration data.
- Only Xchange sensors are sent for calibration, leaving the instrument working in the field.

Base•X is the smallest multi-sensor data logging instrument in the X-Series family. Its compact size makes it ideal for hand deployments from small boats, jetties, suitable shorelines, etc. As Base•X shares the same pedigree as larger, more featured instruments in the X-Series family, it provides the same capabilities, functionality, and accuracy, but in a condensed package.

Base•X is equipped with one primary Xchange™ sensor port (C•Xchange™, CT•Xchange™, SV•Xchange™) and one secondary Xchange™ sensor port (T•Xchange™, P•Xchange™, Tu•Xchange™) and can accept any sensor in the X-Series lineup. The integrated shackle and cage allow for rapid turnaround from shipping case to deployment, as the instrument is stored 'ready to go.' The instrument is capable of logging continuously for 12 hours with a full battery charge and may be deployed up to a depth of 100 m or 500 m.

Supported communication protocols for Base•X are RS-232 or RS-485. The instrument can be powered both internally and externally.

Like all AML logging instruments, Base•X can be equipped with Data•Xchange to add wireless capabilities and enhance data transfer rates. Base•X<sub>2</sub> has these capabilities embedded.

## Where Do I Start?

AML Oceanographic X-Series instruments ship with several manuals on the USB:

- An instrument manual (this Base-X manual) providing an overview on how to use and maintain the instrument;
- A SeaCast manual providing instructions on how to use the software to configure the instrument and review instrument data;
- Xchange™ sensor manuals (C•Xchange, CT•Xchange, SV•Xchange, P•Xchange, T•Xchange, and Tu•Xchange) providing overviews on how to install and maintain each of the Xchange™ sensors;

If you are configuring an instrument for field use or lab testing, begin with the SeaCast manual.

If you are performing instrument maintenance, begin with the instrument manual.

If you are planning to swap an Xchange™ sensor, read the Xchange™ manual corresponding to your sensors.

If you will be using Data•Xchange with your instrument, refer to its manual beforehand.

## Shipping & Receiving

### Receiving an Instrument

When receiving an instrument, perform the following steps to ensure the instrument will be ready for deployment when required:

- Inspect the shipping container, looking for signs of damage. Damage to the shipping container could indicate damage to the instrument inside.
- The shipping package contains the following items, identified above:
  - Base•X instrument
  - Data•Xchange (if purchased)
  - Data/Power cable
  - Red shorting plug
  - Black dummy plug
  - One primary sensor blanking plug
  - One secondary sensor blanking plug
  - USB with manuals and documentation
  - Battery charger and cable
- Inspect for damage
  - Check the cable for slices or gouges
  - Check the connector sockets for corrosion, dirt, and salt deposits
  - Check the pressure case for dents and scrapes
  - Check the sensors for cracks or bends
- Ensure all the Xchange™ sensors are installed tightly. The blue locking sleeve should be tight, and sitting less than 1 mm from the instrument end cap.
- Connect the instrument to a computer with the data cable and perform a scan or monitor if using SeaCast. Check the battery voltage on the output (normally the last column of data, unless calculated parameters have been enabled). It should be between 7.2 and 8.4 volts.

### Returning an Instrument to the Factory

- If shipping for repair or recalibration, obtain an RMA number from the service centre.
- Pack the instrument in its original shipping box to prevent damage during shipping.

An RMA number can be requested using the contact options given in the Support section of this manual.

## Using the Instrument

### Pressure Ratings

Pressure ratings are given for Xchange™ sensors and the entire instrument. **Deployments should never exceed the lower of these two pressure ratings.** For example, a 500m instrument equipped with a 6000 dBar (0-6000m) P•Xchange sensor is limited to deployments of 500m depth or less. Similarly, a 6000m instrument equipped with a 500 dBar (0-500m) P•Xchange™ sensor is also limited to deployments of 500m depth or less.

It is desirable to optimize the accuracy of pressure measurements by using a P•Xchange sensor with a pressure range that closely matches the depth of the deployment.

**Caution: Do not exceed the specified pressure ratings of the P•Xchange sensor, Tu•Xchange sensor, or the instrument housing. Overpressure can result in damage to the sensors and the instrument.**

### Pre-Deployment Procedures

- Upon Receipt
  - Use the Shipping and Receiving instructions to verify the condition of the instrument.
  - Verify that all sensor calibrations are valid for the duration of the deployment. If not, swap the Xchange™ sensors for sensors with valid calibrations or send the Xchange™ sensors to a service centre for recalibration.
  - Lightly lubricate the underwater connectors with 3M silicone spray or equivalent.
- Before leaving the jetty
  - If applicable, verify the P•Xchange pressure range is correct for the deployment.
  - Connect the instrument to a computer using the data cable.
  - Check the instrument memory
    - Save any unsaved memory files.
    - Initialize the memory (Note: This deletes ALL files stored in the instrument memory. Be sure to have a copy of all important logged data before performing this step.).
      - If using SeaCast, click the *Clear Memory* box.
      - If using a Terminal Emulator, send instrument an *INIT* command.


**Caution: Install blanking plugs in all unused sensor ports prior to deployment. Failure to install blanking plugs will result in damage to the connectors.**



Primary Xchange™ mount blanking plug



Secondary Xchange™ mount blanking plug



### Supported Sensor Configurations

Swappable sensors allow you to configure the instrument in a number of different ways. Base•X supports the following sensors:

Primary Port:

- SV•Xchange
- CT•Xchange
- C•Xchange

Secondary Port:

- P•Xchange
- T•Xchange
- Tu•Xchange\*

\* Tu•Xchange is incompatible with C•Xchange and CT•Xchange on Base•X



## LED Indicator

The LED indicator is located next to the data/power connector on the instrument's top endcap. In general, the LED:

- will be on whenever the data/power cable is plugged into the instrument.
- will turn on when the red shorting plug is inserted into the instrument. It will turn off after 5 minutes to conserve power.
- Will, when the instrument is logging and is brought back to the surface, turn on for 5 minutes so that the operator can see that the instrument is still functioning after the cast.



The LED indicator displays are as follows:

- **Solid green:** This indicates the instrument is on and the battery has more than 20% capacity remaining. The instrument is ready to log.
- **Flashing green:** The instrument is logging data and the battery has more than 20% capacity remaining.

Note:

- The flashing green LED will turn off after 5 minutes to conserve power.
- The instrument will not start logging until it is immersed in water and it takes its first sample at the programmed sampling rate.

- **Solid red:** This indicates the instrument is on and the battery has less than 20% capacity remaining.
- **Flashing red:** The instrument is logging data and the battery has less than 20% capacity remaining.

Note:

- The flashing red LED will turn off after 5 minutes to conserve power.
- The instrument will not start logging until it is immersed in water and it takes its first sample at the programmed sampling rate.

- **LED is off with data/power cable attached:** The instrument is not working properly. Consult the Troubleshooting section or call the service department.
- **LED is off with the red shorting plug inserted:** If the shorting plug was inserted less than 5 minutes ago, the instrument is not working properly. Consult the Troubleshooting section or call the service department. If the LED was on for the first 5 minutes after inserting the shorting plug, the instrument is functioning correctly and the LED has turned off to conserve power.

## Configuring Sampling Parameters Using SeaCast

SeaCast is free software provided for use with AML Oceanographic instruments. It can be used to set up an instrument for profiling or monitoring data, as well as downloading, graphing, and exporting the collected data.

Full details on the instrument configuration process and the software's capabilities can be found in the SeaCast manual.

## Configuring Sampling Parameters through the Terminal

Instruments can also be configured for deployment using a terminal emulation program like *HyperTerminal*, *RealTerm*, or *Tera Term*. Communications with the instrument must be established using the correct communications port and settings. The communications settings are 8 data bits, 1 stop bit, no parity, no flow control, and the desired baud rate.

The following steps must be completed by issuing text commands.

Step	Possible Commands
Initialize Memory (erases instrument memory)	INIT
Set Log File Name	SET LOG filename.txt
Set Instrument Time & Date	SET TIME hh:mm:ss SET DATE mm/dd/yy
Set Sampling Parameters	SET SAMPLE RATE CONTINUOUS SET SAMPLE RATE 5/s SET P INC 1 SET SOUND INC 2

The above table provides example commands only; many additional sampling regimes can be established using available commands. Please consult the Commands section of the Appendix for full syntax details on the commands you wish to use.

## Accounting for Atmospheric Pressure Variations at the Surface

Climate and altitude changes can create fluctuations in atmospheric (barometric) pressure. AML's pressure sensors are sensitive enough to detect these variations. When this happens, the instrument's pressure channel may not read exactly zero when data is taken prior to submersion in the water. Nearly all absolute pressure sensors experience atmospheric pressure offsets if they are sufficiently sensitive.

To compensate for this atmospheric pressure offset, AML instruments have the ability to reset the pressure sensor's zero point. This can be initiated using AML Oceanographic SeaCast software or a Terminal emulator command. The compensation does not affect the calibration of the pressure sensor, and can be turned off or recalculated at any time. The compensation factor is applied through the entire calibrated pressure range. Note that this compensation cannot be applied to a built-in Paroscientific Digiquartz sensor, as found in bathyMetrec•X.

Once the atmospheric pressure compensation is applied, it will be applied to all pressure sensor data until it is turned off or recalculated. The setting is written to memory, so it remains set when the instrument is powered down.

### Using SeaCast

Refer to the SeaCast User Manual for instructions on enabling "Zero Depth."

### Using a Terminal Emulator

- Establish serial communications with the instrument on your computer. Refer to the Communications section of this manual for more information.
- Once connection is established, ensure the instrument is stationary, and is not submerged in water.
- To turn ON Atmospheric pressure compensation, issue the *ZERO ON* command. This will calculate and apply the offset required to compensate for current atmospheric pressure conditions.
- To turn OFF Atmospheric pressure compensation, issue the *ZERO OFF* command. This will disable the offset.
- Issuing the *ZERO* command again will calculate a new offset based on current conditions.

### Logging a Profile

- Ensure the pre-deployment procedures have been completed (see page 5).
- Plug the data/power cable into the instrument.
- Ensure that the desired sampling settings have been selected and applied.
- With the instrument in air (NOT submerged), use the *ZERO* command to zero the barometric pressure offset (P•Xchange only).
- Insert the red shorting plug to power the instrument. Insertion of the shorting plug tells the instrument to begin logging data once it is submerged. The instrument determines whether or not it is submerged by looking for valid conductivity or sound speed readings.
  - The green LED light should illuminate on the top of the instrument indicating the battery has more than 20% capacity remaining and the instrument is ready to start logging.
  - If the LED light is red, the battery charge is less than 20% but the instrument is still ready to log.
  - If the LED light fails to illuminate, the instrument will not log. Refer to the Troubleshooting section of this manual if this occurs.
- Securely attach the lowering cable to the instrument shackle bar.
- Lower the instrument until it is just submerged. Keep the instrument at this depth for 2 minutes prior to beginning the cast. This allows the sensors time to wet and the pressure case to shed heat.
- Send the instrument down to the desired depth and return it to the surface.
- Note that with Base•X in the typical, vertical orientation, the downcast data is usually more accurate than the upcast data since the downcast measurements are not contaminated by the thermal shedding from the pressure case.

### Monitoring Real Time Data

- Ensure the pre-deployment procedures have been completed (see page 5).
- Ensure that the desired sampling settings have been selected and applied.

- Plug the data/power cable into the instrument. If you power the instrument externally over a long cable, please note the following:
  - Voltage drop due to cable resistance increases with cable length. The voltage drop on a standard AML cable, with a standard Minos•X, is about 2 volts per 100m of cable while sampling and 0 volts per 100m when in low power mode.
  - The instrument's low voltage warning triggers at 6.9 volts.
  - The instrument's auto shutdown triggers when supplied with 6.5 volts or less.
  - The instrument's maximum voltage is 26 volts.
  - The voltage at the instrument, while sampling, must be above the shutdown level for the instrument to operate.
- With the instrument in air, use the *ZERO* command to zero the barometric pressure offset (P•Xchange™ only).
- Securely attach the lowering cable to the instrument shackle bar.
- Lower the instrument until the sensors are fully submerged; the LED should start to flash green. Keep the instrument at this depth for 2 minutes prior to beginning the cast. This allows the sensors time to wet, and the pressure case to shed heat.
- Begin monitoring data using SeaCast or HyperTerminal.
- Send the instrument down to the desired depth and return it to the surface.
- Note that with Base•X in the typical vertical orientation, the downcast is usually more accurate than the upcast data since the downcast measurements are not contaminated by the thermal shedding from the pressure case.

## Post-Deployment Procedures

- When the instrument is pulled from the water it should be rinsed in fresh water.
- Dry the area around the connectors with a clean cloth or compressed air prior to disconnecting the plugs or cables. **Do not blow compressed air into the Pressure•Xchange™ sensor. Doing so may damage the sensitive pressure transducer diaphragm.**
- Remove the shorting plug or cable. Place dummy plug in the connector to protect it.
- Dry the instrument and stow it securely.

## Viewing your Data

You may download and view data directly through the terminal, or automatically using SeaCast. The SeaCast manual has more information. Alternately, use the following instructions to access the data manually.

- Connect the instrument to the computer using the data/power cable.
- With the terminal, use the *DIR* command to list all the files on memory, then the *DUMP* command to retrieve the file of interest. For example:

```
Base.X Version 4.09 SN:2501
AML Oceanographic Ltd.
968.5 MBytes installed
```

```
>dir
test .raw 5598 02/24/10 14:41:55.00
data .txt 3987 02/24/10 14:45:08.00
```

```
960 MBytes free
7 MBytes Used
```

2 File(s) listed  
>dump data.txt

[cast header]  
InstrumentSN=08221  
Date=02/24/10  
Time=14:45:10.55  
PressureOffset=0.09  
UsePressureOffset=yes  
Slot1Sensor1=SV-C.Xchange SV.X SN 131197 01/22/10  
Slot2Sensor1=P-T.Xchange P.X SN 145721 08/21/09 T.X SN 400048 11/17/09

[Data]  
02/24/10 14:45:10.66 1474.313 0000.015 17.447 008.18  
02/24/10 14:45:10.69 1474.334 0000.015 17.449 008.20  
02/24/10 14:45:11.19 1474.332 0000.027 17.451 008.20  
02/24/10 14:45:11.69 1474.326 0000.027 17.451 008.20  
02/24/10 14:45:12.19 1474.319 0000.027 17.457 008.20  
02/24/10 14:45:12.69 1474.321 0000.034 17.459 008.20  
02/24/10 14:45:13.19 1474.318 0000.023 17.457 008.20  
02/24/10 14:45:13.69 1474.321 0000.019 17.458 008.20  
02/24/10 14:45:14.19 1474.427 0000.019 17.459 008.20  
02/24/10 14:45:14.69 0000.000 -0000.015 17.601 008.20  
02/24/10 14:45:15.19 0000.000 -0000.030 17.655 008.20  
02/24/10 14:45:15.69 0000.000 -0000.011 17.651 008.20  
02/24/10 14:45:16.19 0000.000 -0000.015 17.632 008.20  
02/24/10 14:45:16.69 0000.000 -0000.015 17.624 008.20  
02/24/10 14:45:17.19 0000.000 -0000.015 17.622 008.20  
02/24/10 14:45:17.69 0000.000 -0000.015 17.618 008.20

[cast header]  
InstrumentSN=08221  
Date=02/24/10  
Time=14:45:21.85  
PressureOffset=0.09  
UsePressureOffset=yes  
Slot1Sensor1=SV-C.Xchange SV.X SN 131197 01/22/10  
Slot2Sensor1=P-T.Xchange P.X SN 145721 08/21/09 T.X SN 400048 11/17/09

[Data]  
02/24/10 14:45:21.92 1474.309 -0000.019 17.598 008.20  
02/24/10 14:45:21.95 1474.308 0000.019 17.451 008.20  
02/24/10 14:45:22.44 1474.301 0000.023 17.453 008.20  
02/24/10 14:45:22.94 1474.297 0000.011 17.453 008.20  
02/24/10 14:45:23.44 1474.294 0000.019 17.451 008.20  
02/24/10 14:45:23.94 1474.314 0000.019 17.453 008.20  
02/24/10 14:45:24.44 1474.310 0000.027 17.453 008.20  
02/24/10 14:45:24.94 1474.307 0000.015 17.451 008.20  
02/24/10 14:45:25.44 1474.307 0000.027 17.453 008.20  
02/24/10 14:45:25.94 1474.308 0000.023 17.454 008.20  
02/24/10 14:45:26.44 1474.313 0000.023 17.451 008.20  
02/24/10 14:45:26.94 1474.294 0000.023 17.452 008.20  
02/24/10 14:45:27.44 1474.313 0000.023 17.453 008.20  
02/24/10 14:45:27.94 1474.303 0000.023 17.454 008.20  
02/24/10 14:45:28.44 1474.312 0000.023 17.453 008.20  
>

## Configuring the Instrument for Data on Power Up

Perform the following steps:

- Open a terminal emulation program, such as HyperTerminal. Ensure the serial port has been selected in the program. If the instrument has been set to a specific baud rate with the *SET DETECT* command, the terminal emulation program must be configured for that baud rate.
- Connect the instrument to the computer using the data/power cable.
- Using the terminal emulation program, issue the following commands to the instrument:
  - *SET STARTUP NOHEADER* (disables the power up header information)
  - *SET STARTUP MONITOR* (enables data output on power up)
  - *SET SAMPLE RATE 10/S* (sets the desired sampling rate)
  - *SET DETECT 07* (sets fixed 38400 baud rate)

**Note:** Details on the *SET DETECT* command can be found in the Appendix.
- Unplug the data/power cable from the instrument to turn the instrument off.
- Plug the data/power cable into the instrument to turn the instrument on.

## Disabling Data on Power Up

Perform the following steps:

- Open a terminal emulation program, such as HyperTerminal. Ensure the serial port has been selected in the program. If the instrument has been set to a specific baud rate with the *SET DETECT* command, the terminal emulation program must be configured for that baud rate.
- Connect the instrument to the computer using the data/power.
- Unplug the data/power cable from the instrument to turn the instrument off.
- Hold down the < ENTER > key.
- Plug the data/power cable into the instrument to turn the instrument on.
- Release the <ENTER> key once the prompt '>' is displayed.
- Using the terminal emulation program, issue the following commands to disable data on power up:
  - *SET STARTUP HEADER* (enables the power up header information)
  - *SET STARTUP PROMPT* (disables data output on power up)
  - *SET SAMPLE RATE 10/S* (selects the desired sampling rate)
  - *SET DETECT A7* (sets 10 autobaud attempts then defaults to 38400 baud)


**Note:** Details on the *SET DETECT* command can be found in the Appendix.
- Unplug the data/power cable from the instrument to turn the instrument off.

## Maintaining the Instrument

### Periodic Maintenance

Periodic preventative maintenance will prolong the life of the instrument. The following steps are recommended:

- If the instrument is very dirty or oily, allow it to soak in warm, soapy water before cleaning with a rag or soft brush. When finished, rinse with fresh water to remove any residual soap or dirt.
- Before each use:
  - Check for proper installation of all Xchange™ sensors.
  - Check for nicks and cuts on the cable.
- After each use:
  - Clean and rinse the instrument using fresh water.
  - Dry the instrument completely, and store it in a cool, dry place.
- Monthly:
  - Apply a layer of Molykote 44 medium silicone grease to the female half of the connection as shown and fully insert the plug. Wipe away any excess that squeezes out. This will lubricate both male and female connectors.



- Yearly:
  - Send the instrument or Xchange™ sensors to a service centre for diagnostics and re-calibration.

### Battery Care

Incorrect care can reduce the life of the batteries. Below are some guidelines to prevent damage to the batteries:

- Do not leave the data cable nor the red shorting plug installed in the instrument. This turns the instrument on and depletes the battery.
- Before storing the instrument for several months, fully charge the battery. The battery will self-discharge at a rate of 2% per month so extended storage durations can require recharging to protect the battery from fully depleting.

### Battery Life

Base•X will provide approximately 18 hours of battery life with continuous sampling, however actual life varies somewhat depending on the sensors installed. When logging at time intervals of 25 seconds or more, Base•X powers down between samples to conserve the battery.

The instrument will indicate low battery life when the battery voltage is equal to or lesser than the low voltage threshold, which is factory-set to a default 6.9 V.

## Charging the Lithium-Ion Batteries

- Ensure the instrument is dry.
- Plug the data cable into the instrument.
- Plug the charger into the data cable.
- Plug the charger into a 120 or 240 volt AC outlet and allow the instrument to charge until the green flashing light on the charger turns solid green. A full charge requires approximately 3 hours.
  - If the light on the charger is off, the battery is not attached correctly.
  - If the light on the charger is solid yellow, the battery is on standby.
  - If the light on the charger is flashing red, an error has occurred.

The charger should be connected to the instrument **before** plugging the charger into the AC outlet for proper operation of the charger and charging light.

- Turn the instrument off after charging (unplug the data/power cable) to maintain a full charge after charging.
- If instrument is left turned on after the battery has been charged to 8.3 volts, the charger will turn off and the instrument will start drawing on the battery. When the battery voltage drops below 8 volts the charger will automatically turn on and start charging the battery up to 8.3 volts. The charger can be restarted by manually resetting it (refer to procedure below).
- It is possible to use the instrument while charging the battery, however, instrument use causes the power consumption to fluctuate which can confuse the charger and cause it to stop charging prematurely. The charger monitors the charging power to detect when the battery is charged; fluctuating power from the instrument can corrupt the algorithm. To ensure proper charging, manually reset the charger when you have stopped using the instrument (refer to procedure below).
- **To manually reset the charger:** unplug the charger from the wall and then back in. This will reset the charger and start charging the battery.



## Communications

### PC Settings

Base•X will communicate with both RS-232 and RS-485 serial connections. The computer to which the instrument is connected must be set up as follows:

- 8 bits
- 1 stop bit
- No parity
- No hardware flow control
- Baud rate of 600, 1200, 2400, 4800, 9600, 19,200 or 38,400 baud

After power up, Base•X will wait for an ASCII carriage return. The instrument will automatically detect whether communications are RS-232 or RS-485 as well as the baud rate.

### Output Formats

Output formats can be modified. If the required modifications are not supported by the commonly used command list in the next section, please contact the factory for support with custom output formats.

Formatting can be changed in the following ways:

- The number of decimal places for each channel
- Turn on or off
  - date and time
  - calculated parameters (Salinity and Density)
  - battery voltage
  - power up information (header)
  - automatic monitoring on power up

### Default Output Format

The output from Base•X is space delimited values.

The following table shows the output units for each Xchange™ sensor:

Sensor	Units	Default Format
SV•Xchange™	m/s	1234.567
Conductivity•Xchange™	mS/cm	12.346
CT•Xchange™ Conductivity	mS/cm	12.345
CT•Xchange™ Temperature	C	12.345
Pressure•Xchange™	dBar	1234.56
Temperature•Xchange™	C	12.345
Turbidity•Xchange™	NTU	1234.56

The default data channel outputs with all calculated parameters turned on are:

**SV,P sensors**

Date	Time	Sound velocity	Pressure	Battery	Density	Salinity
mm/dd/yy	hh:mm:ss.ss	m/s	dbar	volts	kg/m <sup>3</sup>	ppt

**SV Turbidity sensors**

Date	Time	Sound velocity	Turbidity	Battery
mm/dd/yy	hh:mm:ss.ss	m/s	NTU	volts

**CT, C,T sensors**

Date	Time	Conductivity	Temperature	Battery	Density	Salinity	Sound velocity
mm/dd/yy	hh:mm:ss.ss	mS/cm	C	volts	kg/m <sup>3</sup>	ppt	m/s

**Note:** These are examples of the default configurations. Your data channel outputs will be entirely dependent on which Xchange™ sensors are installed.

**Default Example Outputs:**

Keyboard inputs in the output capture shown below are in bold type.

```
>Base.X 4.13 SN:0002
AML Oceanographic Ltd.
968.5 MBytes installed

>scan
06/25/13 15:56:40.99 0000.000 0000.22 007.63
>monitor
06/25/13 15:56:47.03 0000.000 0000.14 007.63
06/25/13 15:56:47.53 0000.000 0000.13 007.63
06/25/13 15:56:48.03 0000.000 0000.16 007.63
06/25/13 15:56:48.53 0000.000 0000.22 007.63
06/25/13 15:56:49.03 0000.000 0000.24 007.63
06/25/13 15:56:49.53 0000.000 0000.26 007.63
>dis options
[Instrument]
Type=Base.X
EmulationMode=disabled
UseCustomHeader=yes
SN=2
Firmware=V4.13
SampleUnits=/ second
SampleInterval=2
PressureInc=0.00
SoundInc=0.00
LogFile=data.txt
Date=06/25/13
Time=15:56:58
MemorySize=968.5 MB
MemoryUsed=3.8 MB
DisplayTime=yes
DisplayDate=yes
DisplaySalinity=no
DisplayDensity=no
DisplaySoundVelocity=no
DisplayBattery=yes
RelayMode=RS232 mode
RealtimeLogging=no
```

```
LoggingTimeout=0
StartupDelay=10
DisplayHeader=yes
StartupMode=prompt
CharacterReception=yes
LoggingBreakMode=no
DetectionMode=A3
BatteryACoefficient=+3.500000E-01
BatteryBCoefficient=+2.500000E-02
ShutDownVoltage=6.5
WarningVoltage=6.9
PressureOffset=0.00
UsePressureOffset=no
SoundVelocityThreshold=1375.00
DelimiterMode=Space
SensorDetectionMode=Once
Traceability=yes
SkipPowerOff=no
AnalogChannels=2
```

```
[Slot 1]
```

```
SensorName=SV-C.Xchange SV.X SN 203421 06/07/13
BoardSN=05554
```

```
[Slot 3]
```

```
SensorName=P-T-TU-DO.Xchange P.X SN 303108 04/03/13
BoardSN=55555
>dir
```

```
Demonstr.          2458 04/10/13 04:20:40.00
```

## Support

### Troubleshooting

#### Instrument fails to communicate:

- Is the connector damaged?
- Check the cables
  - Is the data/power cable connected to the instrument and computer?
  - Are there any cuts in the cable?
  - If using a cable other than an AML cable, it should be configured as a null modem cable.
  - If using multiple cable lengths, the extensions should **not** be configured as null modem cables.
- Are the batteries dead? Try using external power.
- If using external power over a long cable, check the voltage drop over the cable. Measure the voltage across a 10 watt, 27 $\Omega$ , resistor across pins 1 and 4 of the cable. The voltage must be above 7 volts.
- Are the communication settings in the program used on the computer correct?
  - Comm port selection
  - 8 bits
  - 1 stop bit
  - No parity
  - No hardware flow control
  - Baud rate between 600 and 38,400 baud
- Are the communication settings in the instrument correct?
  - Was the instrument specifically set to one baud rate last time? If so, use that baud rate to resume communications.
  - Was the instrument set to only RS-232 or only RS-485 last time? If so, resume communications in the required protocol.
  - Was the instrument set to *RX OFF* last time? If so, a carriage return must be sent to the instrument immediately after power is applied to interrupt this mode.
- Was the instrument set to monitor on power up mode? If so, a carriage return must be sent to the instrument immediately after power is applied to interrupt this mode. To interrupt monitor on power up, hold down the ENTER key while applying power to the instrument.

#### Instrument fails to log:

- Verify the LED indicator status:
  - With the instrument in air (NOT submerged), insert the red shorting plug. The LED indicator should show solid green indicating the instrument is charged and ready. **Note: If neither SV•Xchange, CT•Xchange, nor C•Xchange sensors are installed, the instrument will begin logging in air.**
  - Place the instrument's sensors in water. The LED indicator should remain green and begin flashing, indicating the instrument is charged and logging.
    - If the indicator shows red, charge the battery.

- If the indicator does not light up, the instrument is not operating correctly. Continue with the remaining troubleshooting items.
- Allow at least two sample periods for the instrument to detect that it is immersed.
- Was the red shorting plug firmly seated in the instrument?
- Are the batteries dead (LED light does not illuminate when shorting plug is installed)?
- Were the sound velocity increment, pressure increment and/or sample rate settings set to values that could prevent logging?
- Was the log file name set correctly?
- Is the connector damaged, dirty, or corroded?
- If all previous steps fail, reset the instrument. Send an *INIT* command to the instrument to re-initialize the memory.

**Note:** The *INIT* command will completely erase all settings stored on the instrument.

**Instrument generates noisy data:**

- Is the connector damaged, dirty, or corroded?
- If connected to external power, is there noise on the power supply? Switch-mode power supplies are common sources of noise.
- Nearby EMI sources such as electric motors can create noise. If possible, move the instrument and its cables away from the noise source.
- Are the sensor/s clean?
- Are there bubbles on or in the sensor/s?
- Are the sensor/s damaged?
- Is there something nearby affecting the water temperature?

**Battery fails to fully charge:**

- Is the charger connected to the data/power cable?
- If the instrument is used while charging the battery, the changes in power consumption can cause the charger to stop charging prematurely. The charger monitors the charging power to detect when the battery is charged; fluctuating power from the instrument can corrupt the algorithm. To ensure proper charging, manually reset the charger when you have stopped using the instrument (refer to procedure below).
- If the charger light is green but the battery voltage is less than 8 volts, manually reset the charger (refer to procedure below).
- If the charger light is green and the battery voltage is between 8 and 8.3 volts, this is normal. The charger will charge the battery up to 8.3 volts. However, if the data/power cable is left plugged in to the instrument, the instrument will remain on and draw on the battery. When the battery voltage drops below 8 volts, the charger will automatically begin charging the battery up to 8.3 volts. The charger can be restarted at any time by manually resetting the charger (refer to procedure below).
- To stop the battery from draining down to 8 volts, unplug the data/power cable from the instrument as soon as the red light on the charger turns green. This will turn off the instrument.
- **To manually reset the charger:** Unplug the charger from the wall and plug the charger back in. This will reset the charger and start charging the battery.

**SeaCast fails to recognize a sensor:**

- Be sure to download the latest version of SeaCast.
  - Tu•Xchange™ requires SeaCast version 3.0 or greater for full functionality.

## Contact AML Oceanographic

### Service

To request an RMA or technical support

Email: [service@AMLOceanographic.com](mailto:service@AMLOceanographic.com)

Phone: 1-250-656-0771

Phone: 1-800-663-8721 (NA)

Fax: 1-250-655-3655

### Sales

For all general sales inquiries

Email: [sales@AMLOceanographic.com](mailto:sales@AMLOceanographic.com)

Phone: 1-250-656-0771

Phone: 1-800-663-8721 (NA)

Fax: 1-250-655-3655

### Website

<http://www.AMLOceanographic.com>

### Customer Portal

*My AML Oceanographic* is AML's online data centre. This secure area within our website is designed to offer one easy location for interested individuals and organizations - distributors, customers, prospects, and other members of our community - to manage their interactions with AML. *My AML Oceanographic* will allow you to:

- View and manage your assets (instruments and sensors)
- Consult instrument diagnostic summaries
- View and download calibration and conformity certificates
- View and manage your technical support cases
- Consult and download sales estimates, sales orders, and invoice copies
- View account balances and generate account statements
- Assess inventory availability at AML

To access the Customer Portal, please navigate to the *Support* button - located on the top right of the AML Oceanographic home page - select *Customer Centre* from the options on the drop down menu and follow the instructions provided.

### Mailing and Shipping Address

AML Oceanographic

2071 Malaview Ave.

Sidney, BC, Canada

V8L 5X6

## Appendices

### Commands

When using SeaCast, the full command set is not usually necessary. However, text commands are available. Below is a listing of commonly used commands. Note that some commands are only available on instruments equipped with the appropriate Xchange™ sensors.

#### Communications Commands

Command	Description	Requires
SET FORCE 232	Sets com mode to RS-232. Power must be cycled for changes to take effect.	
SET FORCE 485	Sets com mode to RS-485. Power must be cycled for changes to take effect.	
SET FORCE AUTO	Sets for auto-detection of RS-232 or RS-485 comms. Note that if instrument is not connected to a com port on power up, it assumes RS-485 operation and will remain in that mode until powered down.	
DISPLAY FORCE	Displays current com mode (ie RS232, RS485, AUTO)	
DISPLAY DETECT	Displays the baud rate detection settings.	
SET DETECT a b	Sets the baud rate detection. "a" sets the number of autobaud detection attempts before the instrument reverts to the default baud rate set by "b." Setting 'a'=0 forces the instrument to a fixed baud rate determined by "b." "b"= 1 = 600 baud      4 = 4800 baud      7 = 38400 baud 2 = 1200 baud    5 = 9600 baud      8 = 57600 baud 3 = 2400 baud    6 = 19200 baud     9 = 115200 baud	

#### Sampling Rate Commands

Command	Description	Requires
DISPLAY SAMPLE RATE	Displays the time-based sampling rate.	
SET SAMPLE n t	Sets the desired sampling rate. "n" is a number and "t" is the time units. Using the slash (/) character should be read as "per". For instance, 5 s means sampling happens every 5 seconds. 5/s means 5 samples per second. Examples are: SET S C            sets the sampling to continuous (25 Hz) SET S 5 /s        5 samples per sec SET S 1 s         Sample 1 time every 1 second SET S 2 /m        2 samples per minute SET S 5 m         Sample 1 time every 5 minutes SET S 2 /h        2 samples per hour SET S 24 h        Sample 1 time every 24 hours	
DISPLAY INCREMENT	Displays logging increment for pressure in dbar.	P•X
SET PRESSURE INCREMENT n	Sets logging by increment of pressure specified by n = increment value in dBar (resolution of 2 decimal places).	P•X
SET SOUND INCREMENT n	Sets logging by increment of SV specified by n = increment value in m/s (resolution of 1 decimal place).	SV•X
DISPLAY SOUND INCREMENT	Displays the logging increment for sound velocity in m/s.	SV•X



### Output Format Commands

Command	Description	Requires
DISPLAY SCAN	Displays current scan options.	
SET SCAN NOBAT	Turns the battery channel off.	
SET SCAN BAT	Turns the battery channel on.	
SET SCAN NODENSITY	Turns the calculated density channel off.	CT•X and P•X or SV•X, T•X, and P•X
SET SCAN DENSITY	Turns the calculated density channel on.	CT•X and P•X or SV•X, T•X, and P•X
SET SCAN NOSALINITY	Turns the calculated salinity channel off.	CT•X and P•X or SV•X, T•X, and P•X
SET SCAN SALINITY	Turns the calculated salinity channel on.	CT•X and P•X or SV•X, T•X, and P•X
SET SCAN NOSV	Turns the calculated sound velocity channel off, removing it from the instrument output scans. Current salinity display status is viewable using DISPLAY SCAN.	CT•X and P•X
SET SCAN SV	Turns the calculated sound velocity channel on, allowing it to be present in instrument output scans. Current salinity display status is viewable using DISPLAY SCAN. This is only available when CT and P sensors are attached.	CT•X and P•X
SET SCAN TIME	Enables displaying time in data scan	
SET SCAN NOTIME	Disables time from being displayed in data scan	
SET SCAN DATE	Enables displaying date in data scan	
SET SCAN NODATE	Disables date from being displayed in data scan	
DISPLAY STARTUP	Displays the power up output settings.	
SET STARTUP PROMPT	Sets the instrument to wait for user commands on power up.	
SET STARTUP SCAN	Sets the instrument to output one scan on power up and then wait for a user command.	
SET STARTUP MONITOR	Sets the instrument to start monitoring data on power up	
SET STARTUP NOHEADER	Disables the instrument identification header output on power up.	
SET STARTUP HEADER	Enables the instrument identification header output on power up.	

### Logging Commands

Command	Description	Requires
SET SCAN LOGGING	Enables simultaneous logging and real-time output. If real-time logging in air is desired, set instrument conductivity threshold and sound velocity and pressure increments to zero.	
SET SCAN NOLOGGING	Disables simultaneous real-time logging.	
SET TIMEOUT nn	nn is time in minutes from 0 to 30. Enters logging mode after the specified time interval has passed in which the instrument has been idle. Power the unit off, then on, to exit the logging mode. A time interval of 0 will deactivate the command. Setting is viewable using DISPLAY STARTUP.	
LOG	Puts unit into logging mode from real-time mode. It will remain in logging mode until power is turned off.	
SET LOG ttttttt.ttt	Sets new log file name. ttttttt.ttt = log file name. Name can have up to 8 characters in length and 3 characters for file extension.	
INIT	Clears the instruments logging memory.	
DIRECTORY	Displays list of files in instrument memory and memory status including amount of memory space free and used.	
DUMP ttttttt.ttt	Dumps the data of the specified logged file defined by ttttttt.ttt in REAL or RAW format depending on the current instrument mode.	
DELETE ttttttt.ttt	Erases specified logged file defined by ttttttt.ttt Maximum 8 character name with 3 character extension.	
DISPLAY LOG	Displays current log file name.	

### General Commands

Command	Description	Requires
SCAN	Measures and outputs one scan of data.	
MONITOR	Scans at the set sampling rate.	
VERSION	Displays the instrument identification header.	
DISPLAY OPTIONS	Displays the instrument status and user settings.	
ZERO	Corrects the barometric offset to set zero pressure at surface for current barometric pressure.	P•X
ZERO OFF	Disables barometric offset.	P•X
DISPLAYTIME	Displays current time. Time format is hh:mm:ss.ss	
SET TIME hh:mm:ss.ss	Sets instrument time using 24 hour clock in format hh:mm:ss.ss	
DISPLAY DATE	Displays the current date.	
SET DATE mm/dd/yy	Sets date using mm/dd/yy format.	
DETECT	Checks each slot in logger board to identify what is plugged in and displays sensor / board type and serial number or "empty" for each slot.	
DISPLAY BATTERY	Displays battery channel coefficients and shutdown voltage.	
TALK n	Enables communications directly with a sensor board via the logger board, where n = value from 1-3 that identifies the slot number of the board to be communicated with. See DETECT command.	
CTRL+C	Press CTRL key and C key at same time to exit sensor board talk mode & return to logger communications.	

## Technical Specifications

### Electrical

- Mother Board
  - Flash, non-volatile data memory (Minimum 1 GB)
  - Two dedicated slots
    - Primary Xchange™ sensor slot
    - Secondary Xchange™ sensor slot
- Sensor Boards
  - Sound Velocity, CT or Conductivity Xchange sensor board
  - Pressure, Temperature, and Turbidity Xchange sensor board
- Auto detect RS232 or RS485 (½ duplex ASCII)
- Autobaud to 38,400

### Power

- External Power Supply: 6.5 to 26 VDC
- Internal Power Supply
  - Standard: Lithium Ion
    - Capacity: 3 Ah
    - Voltage: 7.2 Volts
- Current Draw
  - 135 mA when sampling
  - 50 mA in standby mode
  - 60 µA when in low power mode
- Battery voltage limits
  - 8.3 volts: Full Charge
  - 6.9 volts: Low battery warning
  - 6.5 volts: Auto shutdown

### Pressure Case

- Environmental Limits
  - Storage: -40°C to 60°C
  - Usage: -20°C to 45°C

Housing					
Type	Depth Rating	Diameter	Length	Weight (in water)	Weight (in air)
Delrin	100 m	2.7" [69 mm]	15.3" [390 mm]	1.1 lb [0.5 kg]	2.6 lb [1.2 kg]
Delrin (with internal aluminum sleeve)	500 m				

Bulkhead Connector				
Type	Pins	Sex	Material	Manufacturer
Bulkhead	Micro 8	Female	SS316	Subconn

### Sampling Capabilities

- Frequency
  - Time: Sample rates from 25 per second to 1 per 24 hours
  - Pressure: Specific pressure increments in 0.01 dbar steps
  - Sound Velocity: Specific sound velocity increments in 0.1 m/s steps
- Configurations
  - Single scan or continuous output
  - On command or autonomous on power up

### Included Items

- Base•X instrument
- 2m Data/Power Pigtail
- Red shorting plug
- Black dummy plug
- One primary sensor blanking plug
- One secondary sensor blanking plug
- USB stick with manuals and documentation
- Battery charger

### Software

- SeaCast

## Ordering Codes

### Instruments


PDC-BSX-P1S1-01	Base•X, 100 dBar, Delrin pressure housing
PDC-BSX-P1S1-05	Base•X, 500 dBar, Aluminum-sleeved Delrin pressure housing

Ordering codes for sensors and accessories can be found at

<http://www.amloceanographic.com/>

## Regulatory Information

This product is compliant within the requirements of CE standards.



## Warranty

AML warrants the instrument for a period of two years from the date of delivery. AML will repair or replace, at its option and at no charge, components which prove to be defective. The warranty applies only to the original purchaser of the instruments and only to instruments and sensors manufactured by AML Oceanographic. The warranty of third party sensors will apply as per the specific vendor's warranty policy. The warranty does not apply if the instrument has been damaged, by accident or misuse, and is void if repairs or modifications are made by other than authorized personnel.



This warranty is the only warranty for new product given by AML. No warranties implied by law, including but not limited to the implied warranties of merchantability and fitness for a particular purpose shall apply. In no event will AML be liable for any direct, indirect, consequential or incidental damages resulting from any defects or failure of performance of any instrument supplied by AML.

## DISCLAIMER

AML reserves the right to make any changes in design or specifications at any time without incurring any obligation to modify previously delivered instruments. Manuals are produced for information and reference purposes and are subject to change without notice.

## **Technical Overview Drawings**

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF AML OCEANOGRAPHIC. ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF AML OCEANOGRAPHIC IS PROHIBITED.



**INSTRUMENT MECHANICAL OVERVIEW**

DIMENSIONS:	15.3 x 2.7" (390 x 69 mm)
MATERIALS:	ACETAL housing 316L cage 316L shackle
MAX DEPTH:	100 m
WEIGHT IN AIR:	1.2 kg (2.6 lb)
WEIGHT IN WATER:	0.5 kg (1.1 lb)
POWER:	1. Internal Li battery, Rechargeable. 7.2 V, 3 Ahrs; 12 hrs continuous operation 2. External power: 6.5 to 26 VDC
ENVIRONMENTAL LIMITS:	-20 °C to 60 °C (storage) -20 °C to 45 °C (operational)
CONNECTOR:	Micro 8, female, SS, Subconn
COMPATIBLE SENSORS:	<ul style="list-style-type: none"> <li>• SV•Xchange (standard)</li> <li>• P•Xchange (standard)</li> <li>• C•Xchange</li> <li>• T•Xchange</li> <li>• Tu•Xchange</li> </ul>

INSTRUMENT SHOWN HERE WITH SV AND P SENSORS INSTALLED

2071 Malaview Ave., Sidney B.C. Canada, V8L 5X6 Ph: (250) 656 0771 Fax: (250) 655 3655  
 THIS DRAWING CONFORMS TO ASME Y14.5-2009  
 DIMENSIONS AND TOLERANCES:  
 UNITS: INCHES [MM]  
 ANGLES: ± 1°  
 FRACTIONS: ± 1/32  
 HOLE SIZES: ± 0.005(0.13)  
 0.00: ± 0.015(0.38)  
 0.000: ± 0.005(0.13)

TITLE:



**BASE•X MECHANICAL OVERVIEW**

B	ADDED ELECTRICAL GA	C.B	13-MAY-13	DRAWN	C.B	DATE	4-APR-13	DRAWING NO.:	SWP-GA-03613	REV		AML NO	PDC-BSX-P1S1-01
A	DRAWING CREATED	C.B	4-APR-13	REVIEWED	D.O	DATE	4-APR-13	MATERIAL:	N/A				
REV	DESCRIPTION	BY	DATE			SIZE	B	SLD FILE NO.:	SWP-MA-03611			SHEET NO.	Sheet 1 of 2




THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF AML OCEANOGRAPHIC. ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF AML OCEANOGRAPHIC IS PROHIBITED.

Communication/Charging Cable Assembly  
AML Part No: SUB-G0574




DETAIL SCALE 2:1  
MICRO 8 BULKHEAD CONNECTOR



Shorting Plug  
AML No: PLG-H0009-1

Locking Sleeve  
AML No: CON-H0020



BaseX Electronics  
EXT PWR  
Signal: Tx(232) or A(485)  
Signal: Rx(232) or B(485)  
PWR/COMM Ground  
Charger +  
Power switch OUT  
Power switch IN  
COMM Power IN



THIS DRAWING CONFORMS TO ASME Y14.5-2009  
UNLESS OTHERWISE SPECIFIED:

DIMENSIONS AND TOLERANCES:  
UNITS: INCHES [MM]  
ANGLES: +1°  
FRACTIONS: ± 1/32  
HOLE SIZES: ± 0.005(0.13)  
0.00: ± 0.015(0.38)  
0.000: ± 0.005(0.13)

ORIGINAL SCALE: 1:4  
HOLE DEPTHS GIVEN FOR FULL DIAMETER.  
SURFACE FINISH: 63

TITLE: <b>BASE-X ASSEMBLY COMMUNICATIONS AND CHARGING INTERFACE</b>		DRAWN C.B	DATE 4-APR-13	DRAWING NO.: SWP-GA-03613	REV PDC-BSX-P1S1-01	AML NO
REVIEWED D.O	DATE 4-APR-13	MATERIAL: N/A	SHEET NO. Sheet 2 of 2			
SIZE B		SLD FILE NO.: SWP-MA-03611				